

▶▶ USING THE MICROPHONE

- The Neumann TLM 102 is connected to the rear of the Grace m103 channel strip - **please do NOT unplug from the back of the Grace m103!**
- Be sure to engage the +48v switch on the left side of the Grace m103.
 - If you'd like to use the SM7b, you can unplug the XLR from the TLM 102, or use a 2nd XLR cable and connect to the front panel of the Clarett
- The Grace m103 channel strip is (as labeled) connected to **Input #5** of the Focusrite Clarett interface, and therefore will appear on input 5 of your DAW. The first 4 inputs of the interface are accessible on the front panel of the Clarett.

▶▶ LISTENING ON THE SPEAKERS

- The Focal Shape series speakers have an eco/"sleep" mode. If the lights are **red**, the speakers are **asleep**. If the lights are **green**, they're **awake**. Turn up the **TC Electronics Monitor Pilot remote** gradually until the lights are **green**.
 - **NOTE:** The large Clarett volume knob should be turned all the way up.
- When using the TC Electronics Monitor Pilot, select "1" to listen through the speakers.
 - You can use the "2" and "3" buttons as makeshift "mute" buttons when switching to headphones, which should be connected to the Clarett.



▶▶ USING YOUR OWN LAPTOP


- If you'd like to connect your own laptop to the interface/microphone/speakers, ask a studio support member for help!
- To speed up the process, head over to the **Focusrite downloads page** and install the Focusrite Control software onto your computer
 - <https://downloads.focusrite.com/focusrite/clarett/clarett-4pre>



▶▶ Check out the back of this page for a signal flow diagram



Have any questions? Come find us!



PRODUCTION SUITE SIGNAL FLOW DIAGRAM

